


8mm Bi-Fold Door for Alcove N2V#



Handling

Be aware toughened glass can shatter if not handled correctly. It should not be subjected to any sharp impact and it is essential to protect the glass by resting it on a soft protective surface during installation such as cardboard or carpeting. It is recommended to wear PPE at all times during installation.



Pre-Installation Checks

1. Please take time to read these instructions prior to installing your product, including the Tray Sizes section below.
2. Check you have the correct product, by looking at the labels on the side of the product packaging.
3. Check all the product components and fixing kits are in the box - these are listed on the next page.
4. Please check the product for defects or damage, once the installation has commenced we cannot accept responsibility for any defects or damage.
5. Before you commence any drilling check there are no hidden electrical cables and/or water pipes.
6. No attempt should be made to re-work the toughened safety glass.
7. The installation of the product should be performed by two persons.
8. It is strongly recommended the product is fitted on a tiled surface or similar waterproof surface - which are tiled and grouted before product is installed.
9. It is strongly recommended that the walls the product is going to be installed on are vertical, and the floor/tray is level.
10. Pictures used are for illustration purposes only, product designs may alter slightly as a result of continuing product development.
11. We do not stipulate where the European Standard Kite Mark should be positioned on the glass when being factory assembled.
12. Please note that some natural misting may occur when you remove this product from its packaging, due to the addition of the glass protection pre-coating. If this does occur this can easily be removed with a soft, dry cloth.

Tray Sizes

Important: You MUST measure your tray before you proceed with installation. The 'Adjustment' displayed in the brochure or on your bespoke customer drawing is the required Alcove tray size - this is at MID Adjustment unless stated otherwise. Refer to Step 1 for a guide on how to measure your tray accurately before proceeding any further - Roman will not be liable if you begin installation without correctly measuring your tray, to the realisation it doesn't fit.


Consumer Guarantee

Please make sure the purchaser/end user completes and returns the guarantee card which is enclosed with this product. Failure to validate the Guarantee will mean only the 1 Year Statutory Guarantee will apply.





REV07 - 11.2025

Equipment Checklist: Not Supplied



Fixing Kit Components




Part No.	Description	Qty	Part No.	Description	Qty	Part No.	Description	Qty
1	Short Wall Profile	1	11	Pivoting Door Assembly	1	21	Adhesive Strip	1
2	Short Vertical Frame	1	12	Long Vertical Frame	1	22	Bottom Flipper Seal	1
3	LH Top Cap	1	13	LH Pivot Cap	1	23	LH Bottom Rail Joiner	1
4	Adhesive Tape	3	14	Universal Top Cap	1	24	RH Bottom Rail Joiner	1
5	Short Cover Plate	1	15	Long Cover Plate	1	25	RH Top Cap	1
6	Frame/Door Magnets	1	16	Long Wall Profile	1	26	-	-
7	Handled Door Glass	1	17	RH Pivot Cap	1	27	-	-
8	Door Handle	1	18	RH Dam Moulding	1	28	-	-
9	Hinge Assembly	2	19	LH Dam Moulding	1	29	-	-
10	Centre Door Magnets	1	20	Bottom Rail	1	30	-	-


Step 1 - Pre-Installation Checks & Aperture Sizes

Your area must be tiled and grouted before measuring your tray - refer to your tray installation instructions and ensure this is done correctly. This is because tray measurements are taken from the tiled wall. Once tray installation is complete you can proceed to measuring the area. The tables below show the range of tray widths which will allow for correct fitment - this is for standard products only. For Bespoke products please refer to your customer drawing for the MID Adjustment of the Door, this is the required Alcove size.

Product Code	Alcove Size (Min)	Alcove Size (Max)
N2V7613#	710mm	750mm
N2V813#	750mm	790mm
N2V913#	850mm	890mm
N2V1013#	950mm	990mm
IMPORTANT: The above are finished tiled sizes		





Measure from one tiled wall to the other.



Use the table above and measure the Tray. We recommend measuring the bottom, middle and top across a 1950mm height.




If your tray exceeds the given amount for your product size, you may need a bespoke product.

Step 2 - Pre-Installation Checks



1. Make sure the tray is installed as per the manufacturer's instructions.
2. Check your Tray and Walls are level on all sides (the bubble on the spirit level must be in the centre of the 2 lines).
 - If the Walls & Tray are not level you will not achieve the +/- 10mm of adjustment.
3. Stand in the tray and check that there is no adverse movement (correct if necessary).
4. The walls should be tiled and grouted up to the tray.
5. The tiles and the tray should be sealed using a good quality bathroom sealant:
 - Spray the seal and joints with the shower head and check for leaks when the silicon has cured.
 - Check the plumbing for leaks.
 - DO NOT plasterboard over the tray.
 - DO NOT grout the tiles when the enclosure has been fitted, the grout may discolour the aluminium profiles.

Step 3 - Fitting the Wall Profiles





1. Decide which side of the alcove the pivot side of the enclosure is to be fitted. Place the longer wall profile 15mm in from the outside of the tray. The longer leg of the wall profile must be on the outside of the enclosure, towards the front of the tray. Make sure the wall profile is completely vertical using a spirit level and mark the wall through the slots with a pencil.
2. Drill the wall with a 6mm Masonry Drill Bit (not supplied) where the wall profile is to be positioned. Fit the wall plugs supplied (if going in to a brick or block wall). If going into a plasterboard wall you will need to purchase appropriate wall fixings. Wipe clear all debris from the tray before referring to the next stage.
3. Where the wall profile is to be positioned on the tray, place a bead of bathroom sealant (not supplied) the width of the wall profile along the tiled wall. Screw the wall profile to the wall with 40mm Screws (supplied). Do not over tighten the screws into the wall profiles as this will misshape the wall profile. Ensure the wall profile remains completely vertical throughout.
 - **No sealant to be present between the wall profiles and the tiled walls vertically prior to screw fixing.**
4. Seal the gap on the inside between the tray and wall profile with a bathroom sealant (not supplied).
 - **Failure to carry out stages 3&4 correctly can result in serious water damage and is not covered by the guarantee.**
5. Repeat these steps for the shorter wall profile on the opposite wall.



Step 4 - Fitting the Door

NOTE: 2 people will be required to carry out these operations. Some parts are hidden for clarity reasons.

1. Dismantle the Handle Assembly and re-assemble onto the Door Glass. Make sure the Plastic Gaskets are fitted between the Handle and the Glass. Ensure the Set Screws are on the inside of the enclosure.




2. Place the setting blocks onto the bottom of the glass, ensuring the end marked "A" is on the glass.
3. Lift the door assembly onto the tray and slide over the longer Wall Profile making certain that the setting blocks are resting on top of the tray.



- **IMPORTANT:** With the setting block resting on top of the tray, ensure that the pivot block on the door side is fully supported and sits flush against the tray top.


4. Slide the Frame Magnet into the channel on the Vertical Frame and offer it over the shorter Wall Profile.
5. Open the door slightly and push the Door Magnet onto the Door Glass at the handle side.



- **Note: Ensure the magnet orientation is the same as the images above.**


Step 5 - Fixing the Door to the Wall Profiles

NOTE: 2 people will be required to carry out these operations. Some parts are hidden for clarity reasons.






- Centralise the Door between the Wall Profiles, there must be a minimum of 10mm for fixing.
 - **Make sure the Magnets on the Door and Frame locate onto each other down the full length of the door.**
- On the inside of the enclosure, with the 2.5mm drill bit (supplied), drill a hole into the Vertical Frame and Wall Profile approximately 100mm from the top and bottom and one in the centre. Drill 2 holes between these (5 holes in total).
 - **Ensure the door is completely vertical (the bubble on the Spirit Level must be in the centre of the 2 lines).**
- Fasten the Door to the Wall Profiles using the 9mm screws supplied.
- Seal the Wall Profiles vertically top to bottom, both internally and externally where they meet the tiles.
 - **IMPORTANT: Failure to carry out stage 4 may result in serious water damage and is not covered under the terms of the guarantee.**
 - **Allow 24 hours for the sealant to fully cure prior to using the shower.**
- Remove the setting blocks from the bottom of the door.

Step 6 - Fitting the Dam & Bottom Rail








- Choose the correct dam for your installation and discard the other.
- Turn the dam upside down and add a small amount of sealant on the inside edge (see image).
- Seal the base of the pivot section to the tray top as shown in the image above.
- Position the dam against the vertical frame at the pivoting side of the door and gently press into the sealant just applied.
 - **IMPORTANT: The dam must be fitted before the pre-applied sealant starts to cure.**
- Choose the correct bottom rail joiner, turn it upside down and add a small amount of sealant to the inside edge. Seal the outside of the vertical frame and wall profile to the tray top as shown.
- Position the bottom rail joiner against the vertical frame at the closing side of the door.

Step 6 Continued... Fitting the Dam & Bottom Rail








7. Remove the release paper from the back of the adhesive tape (which is on the underside of the bottom rail) and place the rail inside the dam and bottom rail joiner.
 - **The bottom rail joiner will need lifting slightly to allow positioning of the bottom rail.**
8. Press the rail down onto the top of the tray ensuring that it is kept parallel to the outside edge of the tray and that the dam and joiner both remain in position.
 - **Make sure the top of the tray is clean and free from any contaminants before applying the rail.**
9. Make sure the door magnet is positioned so it just clears the bottom rail when the door is opened. The magnet may need to be removed and repositioned to achieve this. Trim both magnets so that they are level with the top of the glass.

Step 7 - Fitting the Door Seals and Sealing



1. Seal the base of the enclosure to the top of the tray from wall to wall on the outside only making sure that you seal around the Dam and Joiner as shown. Seal the Dam vertically where it meets the Vertical Frame.
 - **IMPORTANT: Failure to carry out stage 1 may result in serious water damage and is not covered under the terms of the guarantee.**
 - **DO NOT seal the base of the product to the inside, failure to comply may result in the product leaking.**
 - **Allow 24 hours for the sealant to fully cure prior to using the shower.**
2. Cut the Bottom Seal in half using snips to get two Seals. Measure between the Pivot Tube and where the Centre Magnets meet and cut one Bottom Seal to this length. Do the same for the other Bottom Seal, measuring between the Angled Magnet and where the Centre Magnets meet.
 - **Make sure the rebate end of the seal is kept for the pivot side of the door.**
 - **Ensure the Magnets on the door and frame locate onto each other down the full length of the door.**
 - **If the Seal drags over the Bottom Rail, the door may need raising at the magnet side. Unscrew the top 3-4 door fixing screws, raise the door, re-drill and re-fix.**
3. Remove the Centre Magnets from the Door Glass. Fit the Bottom Seals to the Door Glass and put the Centre Magnets back on the Door Glass. Ensure the Magnets sit on top of the Bottom Seals. Trim the Magnets so they are level with the top of the glass.
4. Ensure the Door Centre Magnets locate fully from top to bottom when the door is closed. They can be knocked towards each other using a wooden baton.

Step 8 - Fitting Screw Covers and Caps



1. Remove the release paper from the Adhesive Tape supplied and place the Tape on the face of the Vertical Door Frame, ensuring the Tape is positioned to one side of the screw heads.
 - **The longer Cover Strip is for the pivot side of the product.**
2. Place one side of the Cover Strip over the leg on the Vertical Frame and press firmly to stick the Cover Strip to the Frame.
 - **Both Cover Strips should sit on top of the tray.**
3. The Top Caps have grooves and can be shortened by cutting along these grooves using scissors or snips (adding a small amount of sealant will help keep the caps in place).
4. Place the Branding Badge in a prominent position on a none moving part of aluminium.

Trouble Shooting Guide

Should you experience any problems during installation please refer to the Trouble Shooting Guide or contact Customer Relations on:
+44 (0) 1325 328033

To enable customer relations to provide you with an excellent level of service it is important that you quote your product Code and Reference Number - these can be found on the Guarantee card.

Problem	Solution
Leaking	1. Check that the inside gap between the tray and wall profiles has been sealed correctly. 2. Ensure the tray is sealed along the tiled walls prior to installation. 3. If the inside joint between the enclosure and the tray top is sealed, this will cause leakage - sealant must be removed. 4. Ensure the wall profiles on the tiled walls are sealed both vertically inside and outside. 5. Ensure the joint between the enclosure and tray top is sealed. 6. The deflector on the bottom seals is semi rigid and can be carefully altered to offer more deflection of the water. 7. Check the angled magnets are locating and there are no gaps. Important: This enclosure should be water tested conforming to BS EN 14428
Enclosure Alignment on Tray	1. Is the enclosure fitted onto a tiled wall? 2. Are the wall profiles fitted 15mm from the outside edge of the tray? 3. Is the wall profile completely vertical?
Door not operating correctly	1. Ensure both wall profiles are completely vertical. 2. Ensure the tray is completely level.
Door Alignment	1. Ensure both Wall Profiles are completely vertical and inline with each other. 1. Ensure the tray is completely level

Please Note

DO NOT attach or hang items, such as shampoo holders, shower baskets etc. onto this product.
Failure to do so may result in damage to the glass or even glass breakage.

Important Information to help you maintain your Product:

The following information is all you need to keep your product looking new.

Our products are generally maintenance free, however it may be necessary to lubricate wheel assemblies and other moving parts such as hinges from time to time.

Clean your product using a mild detergent diluted in water and then polished off using a soft cloth.

If you live in a hard water area, periodically clean your product using a 50/50 solution of white vinegar and water. The solution should be left on the enclosure for approximately 5 minutes then rinsed off using warm water. This method of cleaning should remove lime scale residue. It is strongly recommended that a quality silicone spray is used.

A list of Donts

1. Don't use acidic based products which are unsuitable for cleaning enamel surfaces.
2. Don't use abrasive cleaners or cleaners using bleach or solvents, these products will adversely affect the finish of the aluminium profiles.
3. Don't use scouring pads, powder or any sharp instruments when cleaning the enclosure.